


Upgrade Instructions


1. Log into the MAP Gateway user interface with an Administrator or Service role using a mobile device or laptop that supports file transfer (non-iPhone/iPad).
2. Open the navigation menu from the UI and choose **Settings**.




3. Under Settings choose **Software Updates**.




4. Select the MAP Update file (MAP.x.x.xxx.bin) from the **Choose File** dialog.



5. Select **Upload** from the Software Updates dialog. The MAP Gateway will upload the file and store it locally on the device.



6. After the MAP Gateway has validated the uploaded file contents, select **Install** to apply the updates.



7. While updates are applied:
 - a. The red Fault LED in the MAP Gateway will flash
 - b. All MAP users are logged out automatically
 - c. The Wi-Fi connection will be disabled